





ORTEGA®
GUITARS • EST 1994

USER MANUAL

Magus-X

ORTEGA ACTIVE PREAMP SYSTEM

FUNCTIONS



- ① **VOLUME:** Master volume control
- ② **BASS:** Provides desired amount of bass response
- ③ **MIDDLE:** Provides active midrange equalization with boost & cut
- ④ **TUNER:** Tap to enable the tone calibration mode



All the opening sound is displayed



Low tone correction display



According to the calibration tone, Turn green at the same time



The tone correction is high

- ⑤ **TREBLE:** Provides high frequency equalization as required
- ⑥ **CHARGING MOUTH:** Charge for 5 minutes and use for 10 hours
- ⑦ **INDICATOR LIGHT:**
 - (1)When charging, the green light comes on and the rear light goes off
 - (2)The green light turns on when working normally
 - (3)When the battery is low, the light is red
- ⑧ **OUTPUT WIRE SOCKET**
- ⑨ **PICK UP BAR INPUT PORT**

SPECIFICATION

- Nominal Input Level: -20dBV
- Nominal Output Level: -17dBV
- Input Impedance: >1M Ohm (60Hz~18KHz)
- Volume Control
- Bass:±12dB
- MIDDLE:±12dB
- TREBLE:±12dB
- Low-battery Indicator
- Lithium-ion Capacitance
- USB TYPE-C Charging

